

***ELEMENT_BLANKING**

Purpose: This keyword is used to define a part set to be used in keyword *DEFINE_FORMING_BLANKMESH for a blank mesh generation.

Card 1 1 2 3 4 5 6 7 8

Variable	PSID								
Type	I								
Default	none								

<u>VARIABLE</u>	<u>DESCRIPTION</u>
PSID	Part set ID, defined by *SET_PART.

Remarks:

1. This keyword is used in conjunction with *DEFINE_FORMING_BLANKMESH to generate mesh on a sheet blank for metal forming simulation.
2. This feature is available in LS-DYNA R5 Revision 59165 or later releases.

***ELEMENT**

***ELEMENT_BLANKING**
